



INSTALLATION INSTRUCTIONS

1. Disconnect negative battery cable.
2. Thoroughly clean bung's mounting surfaces and threads to insure a good leak-free seal.
3. With washer and hex nut in place, insert petcock into gas tank and turn nut clockwise to engage threads on petcock and gas tank. Set outlet at desired position and gently tighten the nut.

Warning: Do not attempt to use outlet fitting to position petcock direction after tightening nut!

If installing 3/8 NPT petcock:

1. Use a little Teflon tape.
2. Hand-tighten only: You may use your fingers on the fitting and lever to hand-tighten petcock. Experiment with the Teflon tape to reach the desired position of the petcock.
3. Last step is to apply a thread sealant compound to the I.D threads in the tank. We recommend LACO's slic-tite paste (www.laco.com). Let paste dry before adding gasoline (follow manufacturer's instructions).